



Without PCB board, you can just connect the pins as shown in this schematic. It works OK, because I have done that. I recommend you to connect the whole pins if you want to make PCB.

Title			MiniMP3	
Size	Number		Revision	
B			V1.0	
Date:	2007-1-1		Sheet of	
File:	E:\DIY\MP3\schematic\mp3.SchDoc		Drawn By:	
			bozai(章其波)	