

# 11076 TCH

## “The Magic Touch” – Capacitive Touch Sensors

# Class Objective

## When you finish this class you will:

- Explain the environmental factors affecting capacitance
- Demonstrate a capacitive touch sensor interface
- Write software that can differentiate a touch from environmental factors

# Agenda


- **Basics of Capacitance**
- **Measuring capacitance**
- **Detecting a touch**
  - Basic system
  - Multi-Button systems
  - Advanced topics

# Capacitance Basics

# Capacitance

Any two conductors form a capacitor

$$C = \frac{\epsilon_0 \epsilon_r A}{D}$$



- C** Capacitance (Farads)
- $\epsilon_0$**  Permittivity of free space (8.854 pico-Farad/meter)
- $\epsilon_r$**  Relative permittivity of dielectric material (unit-less)
- A** Area of plate (meters)
- D** Distance between plates (meters)

# Factors Driving Capacitance

- **Size of sensor Pad**
- **Amount of Finger covering sensor**
- **Material covering the sensor**
- **Thickness of Material covering Sensor**
  - Protective coverings
- **Materials on fingers**
  - Gloves
  - Paint

# Touch Button Control

- **Hand effects in radios**
  - Holding the knob affected tuning
  - Armatures of tuning capacitors were grounded to stop effect
- **The Theremin or Thereminvox was the first fully electronic musical instrument**
- **Touch Lamps**


# Measuring Capacitance



# Capacitance Measurement


## ● Measurement Challenges

- Typical sensor capacitance between 8 and 100pF
- Typical shift due to touch 0.5% - 10%
- Possible environmental shifts of 1% - 15%





# Impedance Method

- Touch increases capacitance resulting in greater attenuation of oscillator signal





# Time Measurement

- Capacitor is charge from a fixed resistor until a threshold voltage is reached
- Small Capacitance and current, limit time of charge and resolution





# Charge Balancing

- Unknown (touch) capacitor is charge to known voltage
- Switched in parallel to known capacitor
- Count number of unknowns to charge known capacitor



# Frequency Measurement

- Touch sensor is the C in an RC oscillator
- Counters form frequency counter
- Longer period increases resolution
- Method tends to average noise



# Frequency Method and Tool Demo

# Microcontrollers with the SR latch mode

- **The SR latch mode of the comparators is relatively new**
  - PIC16F616, PIC16HV616
  - PIC16F690 family
  - PIC16F88X family
  - New! PIC16F72X with expanded sensor inputs and T1G enhancement

# The dielectric constant of materials

- **Glass:**
  - Iron-sealing glass            8.38 to 8.30
  - Soda-borosilicate            4.97 to 4.84
  - Fused quarts                3.78
- **Plastic**
  - Acitrate                      3.48 to 3.30
  - Epoxy resin                 3.67 to 3.52
  - Polycarbonate              3.02 to 2.96
  - Polyethylene               2.26
- **FiberGlass**
  - FR-4                         4.20 to 4.70
- **Other**
  - **Liquid water**              **78.20**
  - Ketchup / Mustard        24.0
  - Ice                            4.15
  - Snow                         1.55






# Differentiating a Touch

# Touch versus environment

- **Heat, Humidity, adjacent metal, and environmental shift 5% - 25%**
- **Touch, with good sensors .8% - 20%**
- **The difference is the rate of change!**
- **What we need is a reference level**

# Touch versus environment



# Sources of Stray Capacitance

- **Adjacent pins**
- **Adjacent traces**
- **Metal cabinet**
- **Tables / chairs**
- **Hemoglobin**
  - Hands, Fingers, other body parts




# Reference Methods

- **Periodic Calibration**
  - Every 3-20 seconds grab a new average
- **Gated Average**
  - If value is outside of guard band don't include in average
- **Slow Average**
  - Include every 8<sup>th</sup> -10<sup>th</sup> sample in continuous running average

# Two-Byte, 16 cell average

- Typical average requires storage of last 16, two byte values
- RC filter style average requires just two bytes.



$$DIFF = AVG - (LAST * 16)$$

$$DIFF = DIFF / 16$$

$$AVG = AVG + DIFF$$

# Gated Average

- **Gate value defines window of values included in average**
  - Fast change in environment can push new average outside window
- **Threshold, referenced to average, determines minimum shift for touch**
  - Lower thresholds have greater sensitive
  - Low threshold can cause phantom touch when other sensors are touched

# Slow Average

- **Requires samples for average to be periodic**
  - May miss quick changes resulting in slower tracking of environment
- **Requires Set/Reset type of debounce**
  - Threshold operates on either side of average for press and release
  - Requires an intelligent debounce routine to handle touch and release as a press



# Gated and Slow Average Demos


# Multi-Button Touch

# More than 4 buttons


- **Comparators have 4:1 analog mux**
- **Expansion through “paired press” method**
  - Complicated decoding of buttons
  - Only requires 4 average values for 10 buttons
- **Expansion through external multiplexer**
  - Requires additional hardware
  - Requires an additional average value for each button
- **Hybrid of both solutions**

# “Paired press” Method

- Expands 4 buttons to 10
- 1, 3, 7, & 9 are whole buttons
- 2, 4, 5, 6, 8, & 0 are paired press buttons
  - Paired press only produces  $\frac{1}{2}$  the capacitance shift
  - Requires scan of all buttons for a valid decode
  - Can not differentiate two buttons pressed from a paired press




# Paired Press Schematic



# Multiplexer

- **Requires I/O to drive select lines**
- **Requires average value for each button**
  - Is not limited to single button press

# Multiplexer Schematic



# Multi-Touch Demo



# Advanced Topics

# Prior Press

- **Button pressed at code start**
  - Gated average requires logic to recognize positive frequency shift at release and resets average
  - Slow Average ignores a release without a press

# Water Hazard

- **Water couples touch to all wet buttons**
  - Use surface that “beads” the water
  - Isolate buttons with ground plane
  - To differentiate correct touch
    - **First determine percentage of touch**
    - **Compare with all buttons**
    - **Most touched button is primary touch**

# Condiment Conundrum

- **Catsup & Mustard will hold an offset in the average**
  - If slow average, ignore and average will drift to new value
  - If gated average, add logic to detect shift on shift, or add a timeout for press that resets the average
  - Valid press must have press and release

# Metal Tops and Holding Hands

- **Environment shifts all buttons together**
  - Determine degree of touch
  - If multiple buttons pressed equally
    - **Gated Average**  
**Reset average to new level**
    - **Slow Average**  
**Ignore press**

# Touch Demo

# Summary

- **Capacitance is formed by any two conductors separated by a dielectric**
- **Capacitive sensor are affected by touch, and their environment**
- **Measuring capacitance is a hardware / legal challenge**
- **Determining a touch is primarily a software challenge**

# References

- **AN-1101 Intro to Capacitive Touch**
- **AN-1102 Touch Sensor Layout**
- **AN-1103 Touch Sensor Software**
- **AN-1104 Implementing Multibutton**
- **DemoBoards (TBA)**



# Demo Board / Software used in Class

- **Basic Four Button Demo board**
- **Paired Press Demo board**
- **Multiplexed Demo board**
- **Touch button GUI**

# Trademarks

The Microchip name and logo, the Microchip logo, Accuron, dsPIC, KeeLoq, KeeLoq logo, microID, MPLAB, PIC, PICmicro, PICSTART, PRO MATE, rfPIC and SmartShunt are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

AmpLab, FilterLab, Linear Active Thermistor, Migratable Memory, MXDEV, MXLAB, SEEVAL, SmartSensor and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, ECAN, ECONOMONITOR, FanSense, FlexROM, fuzzyLAB, In-Circuit Serial Programming, ICSP, ICEPIC, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, PICKit, PICDEM, PICDEM.net, PICLAB, PICtail, PowerCal, PowerInfo, PowerMate, PowerTool, REAL ICE, rfLAB, Select Mode, Smart Serial, SmartTel, Total Endurance, UNI/O, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.